













BASS DRUM			SNARE DRUM		LOW TOM	MID TOM	HI TOM	RIM / CLAP	HI HAT		CRASH	RIDE
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
LEVEL	TUNE	TUNE DEPTH	LEVEL	TUNE	LEVEL	LEVEL	LEVEL	RIM LEVEL	LEVEL	TUNE	LEVEL	LEVEL
<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
ATTACK	DECAY	TUNE DECAY	TONE	SNAPPY	TUNE	TUNE	TUNE	CLAP LEVEL	CH DECAY	OH DECAY	TUNE	TUNE
<input type="radio"/>					<input type="radio"/>	<input type="radio"/>	<input type="radio"/>					
DISTORTION					DECAY	DECAY	DECAY					


A B Bank C D







START  STOP/CONT. 

Pattern Play  Track Play 
 Pattern Write  Track Write 

   
 Flam Write Mode Tap Write

Enter /    
 FILL Total accent



 Tempo

Chain
 Set Clear
 Prev meas.   Next meas.
 Last step Scale
 Instr. Last step   Delete meas. Clear track
 Shuffle/Flam Clear
 Instr. sel.   FUNC



MR-9090
RHYTHM COMPOSER

16 x 2 LCD


 Volume

<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
-----------------------	-----------------------	-----------------------	-----------------------	-----------------------	-----------------------	-----------------------	-----------------------	-----------------------	-----------------------	-----------------------	-----------------------	-----------------------	-----------------------	-----------------------	-----------------------

1 Bass drum 2 Snare drum 3 Low tom 4 Mid tom 5 Hi tom 6 Rim shot 7 Hand clap 8 Closed hi-hat 9 Open hi-hat 10 Crash cymbal 11 Ride cymbal 12 13 14 15 16

FUNC:	NAME	COPY P.	PASTE P.	ROL P.	ROR P.	DUMP P.	COPY I.	PASTE I.	ROL I.	ROR I.	RANDOM I.	DUMP ALL	SETTINGS	
NAME:	abc	def	ghi	jkl	mno	pqrs	tuv	wxyz	number	space		delete	previous	next
SETTINGS:	DIN IN	DIN OUT	MIDI IN	MIDI OUT	NOTES IN	NOTES OUT	CHANNEL					[select]	[on]	[off]